

P **WER TAG**

OWNER'S MANUAL

Laser Tag Gun, Vest & Battle Blaster
6 Player Bonus Pack
For ages 8+

Contents:

- 4 Power Tag Guns
- 4 Power Tag Vests
- 2 Battle Blasters

Item #8987


SET UP

- Locate the battery compartment on the top of the Power Tag Gun and back of the Power Tag Vest and Battle Blaster.
- Unscrew each compartment using a 5mm phillips head screwdriver.
- Insert 3 AAA batteries in the Vest and 4 AA batteries in the Gun and Battle Blaster.
- Ensure the + and - signs match up as indicated on each unit
- Close the covers and tighten the screws..

GEARING UP

POWER TAG VEST

- Position the vest in the center of your chest and pull the elastic strap over your head.
- Pull the bottom strap around the side of your back and fasten the fastener head to the opposite side of the vest ①
- Lock the vest fastener into the front-side of the bottom corner of your vest. Align the plastic pin to the hole and pull until you hear a slight click.
- Flip the red switch on the back of the vest ② to the "on" position.
- Default color will appear blue on your team light indicator ③
- Choose your team color on the front side of your vest with the button located on the top of the vest ④. This can be one of four team colors: Blue, Green, Red and White.



POWER TAG GUN

- ① Use the switch on the right side of the gun in front of the trigger to turn it on.
- The gun's team light indicator ② will light up as the default blue team color with the startup sound effect
- Match your team color on your Gun to your Vest using the smaller left button above the trigger ③
- The button to the right will select your gun mode ④. The light will flash and you will hear a sound when you change between gun modes.



PISTOL

- 12 shots before reload
- 1 damage per shot



SHOTGUN

- 6 shots before reload
- 2 damage per shot



MACHINE GUN


- 6 bursts before reload
- 2 damage per shot



ROCKET LAUNCHER


- 1 blast before reload
- 3 damage per blast

- Pull the trigger (5) to shoot
- When you hear a clicking sound, you are out of ammunition. Reload by hitting the button under the handle of your gun (6), the light will flash and you will hear the reload sound.



BATTLE BLASTER

- Grip the bar at the front of the glove with your fingers.
- Securely fasten the strap around your forearm.
- Turn on the Battle Blaster using the button at the rear of the glove (1)
- Select your team color using the smaller left sided button (2) under the team indicator light (3)
- The top button under the team indicator light and the button to the right side of the hand grip will select your gun mode (4). The light will flash and you will hear a sound when you change between gun modes.



FOR EXCITING NEW IDEAS ON HOW TO BATTLE WITH YOUR POWER TAG KIT, VISIT OUR BLOG AT WWW.THEPOWERTAG.COM/BLOG

FOR MORE DETAILED INSTRUCTIONS, WATCH THE VIDEOS AT WWW.THEPOWERTAG.COM/INSTRUCTIONS

POWER SAVING MODE

- To preserve battery life, the Vest, Gun and Battle Blaster will enter power saving mode after 3 minutes of inactivity and power off.
- After 1 minute of inactivity, your gear will make a sound.
- After 2 minutes of inactivity, your gear will make another sound.
- After 3 minutes of inactivity, your gear will make a final sound and turn off.
- After entering this mode, each player must turn the power switch on each device off and on again, hit the team button and then turn on again.
- Power saving mode is a built-in function that saves battery power, enabling players to get more life out of their batteries and gives peace of mind if they accidentally leave any of their devices on after play.

Disclaimer:

- The infrared beam may hit outside of the target zone.
- There is no guarantee that your shot will register accurately every time.
- Turning off the devices and then back on again will reset the weapons and the game starts over.
- Covering the receivers may cause difficulty in shots registering.
- Works up to 150ft in low light, effectiveness in brightly lit environments may decrease this range.
- Adult supervision is recommended.
- Do not mix old and new batteries.
- Do not mix alkaline, standard carbon-zinc or rechargeable nickel-cadmium batteries.
- Non-rechargeable batteries must not be recharged.
- Rechargeable batteries must be removed from the toys before being charged.
- Exhausted batteries must be removed from the toy.
- Be cautious of the Vest strap.
- This product does not use lasers. It uses infrared technology with a 941.6nm wavelength. The beam is not visible to the human eye.
- Conforms to toy safety regulations of ASTM F963, CPSIA, EN71-123, EN60825-1, and ROHS

Infrared -1mW

Power Tag is proud to offer superior customer service;
ensuring your satisfaction, every time!

Visit

www.thepowertag.com

for more information.

 **WARNING:**

CHOKING HAZARD - Small Parts.
Not for children under 3 years.

Imported by
**Concept
Sensations**

Wilmington, Delaware 19805
www.thepowertag.com



Item #8987
made in China
072018